

# **RADIOSS User's Code Interface**

## **2017 version – January 2017**

### **Appendix**

### **Chapter 9**



Altair Engineering, Inc., World Headquarters: 1820 E. Big Beaver Rd., Troy MI 48083-2031 USA  
Phone: +1.248.614.2400 • Fax: +1.248.614.2411 • [www.altair.com](http://www.altair.com) • [info@altair.com](mailto:info@altair.com)

## TABLE OF CONTENTS

<b>9.0 Appendix</b>	
9.1 Appendix 1 – Available User's Arguments	<a href="#">3</a>
9.2 Appendix 2 – Communication between User's Subroutines and RADIOSS Code	<a href="#">9</a>
9.3 Appendix 3 – General User's Subroutine Format with Material Laws 29, 30, and 31	<a href="#">14</a>
9.4 Appendix 4 – General User's Subroutine Format with Extended User Material Laws	<a href="#">16</a>

**9.1 – Appendix 1 – Available User's Arguments**

9.1.1 Available Starter User's Arguments

<b>Starter User's Arguments – Material Law for Shells</b>				
<b>Variable</b>	<b>Size</b>	<b>Type</b>	<b>Write/read</b>	<b>Definition</b>
IIN	1	Integer	R	Input file unit (Starter input file)
IOUT	1	Integer	R	Output file unit (Starter output file)
UPARAM	NUPARAM	Float	W	User's parameter
MAXNUPARAM	1	Integer	R	Maximum size of UPARAM
NUPARAM	1	Integer	W	Size of UPARAM
NUVAR	1	Integer	W	Number of user's variables
IFUNC	NFUNCT	Integer	W	Function number array
MAXNFUNC	1	Integer	R	Maximum size of IFUNC
NFUNCT	1	Integer	W	Size of IFUNC
PARMAT	3	Float	W	(1) Stiffness modulus for interface (2) Young modulus (for shell) (3) Poisson's ratio (for shell)

<b>Starter User's Arguments – Material Law for Bricks</b>				
<b>Variable</b>	<b>Size</b>	<b>Type</b>	<b>Write/read</b>	<b>Definition</b>
IIN	1	Integer	R	Input file unit (Starter input file)
IOUT	1	Integer	R	Output file unit (Starter output file)
UPARAM	NUPARAM	Float	W	User's parameter
MAXNUPARAM	1	Integer	R	Maximum size of UPARAM
NUPARAM	1	Integer	W	Size of UPARAM
NUVAR	1	Integer	W	Number of user's variables
IFUNC	NFUNCT	Integer	W	Function number array
MAXNFUNC	1	Integer	R	Maximum size of IFUNC
NFUNCT	1	Integer	W	Size of IFUNC
STIFINT	1	Integer	W	Stiffness modulus for interface

<b>Starter User's Arguments – Spring Property</b>				
<b>Variable</b>	<b>Size</b>	<b>Type</b>	<b>Write/read</b>	<b>Definition</b>
IIN	1	Integer	R	Input file unit (Starter input file)
IOUT	1	Integer	R	Output file unit (Starter output file)
NUVAR	1	Integer	W	Number of user's variables
UVAR	NUVAR* NEL	Float	R/W	User's variable
PARGEO	*	Float	W	(1) Skew number (2) Stiffness for interface (3) Front wave option
NEL	1	Integer	R	Number of elements
IPROP	1	Integer	R	Property number
IX	3* NEL	Float	R	Spring connectivity
XL	NEL	Float	R	Element length

<b>Starter User's Arguments – Spring Property</b>				
<b>Variable</b>	<b>Size</b>	<b>Type</b>	<b>Write/read</b>	<b>Definition</b>
MASS	NEL	Float	W	Element mass
XINER	NEL	Float	W	Element inertia (spherical)
STIFM	NEL	Float	W	Element stiffness (time step)
STIFR	NEL	Float	W	Element rotation stiffness (time step)
VISCM	NEL	Float	W	Element viscosity (time step)
VISCR	NEL	Float	W	Element rotation viscosity (time step)

<b>Starter User's Arguments – Solid Property</b>				
<b>Variable</b>	<b>Size</b>	<b>Type</b>	<b>Write/read</b>	<b>Definition</b>
NEL	1	Integer	R	Number of elements
IIN	1	Integer	R	Input file unit (Starter input file)
IOUT	1	Integer	R	Output file unit (Starter output file)
NUVAR	1	Integer	W	Number of user's variables
UVAR	NUVAR* NEL	Float	R/W	User's variable
PARGEO	*	Float	W	(1) Skew number (2) Stiffness for interface (3) Front wave option
IPROP	1	Integer	R	Property number
IMAT	1	Integer	R	Material number
SOLID_ID	NEL	Integer	R	Solid Element id t=0
EINT	NEL	Float	W	Total internal energy t=0
VOL	NEL	Float	R/W	Initial volume
OFF	NEL	Float	R/W	Delete flag
RHO	NEL	Float	R/W	Density
SIG	6*NEL	Float	R/W	Stress tensor
XX1	NEL	Float	R	X coordinate node 1
YY1	NEL	Float	R	Y coordinate node 1
ZZ1	NEL	Float	R	Z coordinate node 1
XX2 . . ZZ8	NEL	Float	R	Same for node 2 to 8
VX1	NEL	Float	R	X velocity node 1
VY1	NEL	Float	R	Y velocity node 1
VZ1	NEL	Float	R	Z velocity node 1
VRX1	NEL	Float	R	X rotational velocity node 1
VRY1	NEL	Float	R	Y rotational velocity node 1
VRZ1	NEL	Float	R	Z rotational velocity node 1
MAS1	NEL	Float	W	Mass node 1
MAS2 . . MAS8	NEL	Float	W	Same for node 2 to 8
INN1	NEL	Float	W	Inertia node 1
INN2 . . INN8	NEL	Float	W	Same for node 2 to 8
STIFM	NEL	Float	W	Element stiffness (time step)
STIFR	NEL	Float	W	Element rotation stiffness (time step)
VISCM	NEL	Float	W	Element viscosity (time step)
VISCR	NEL	Float	W	Element rotation viscosity (time step)

<b>Starter User's Arguments – Sensor</b>				
<b>Variable</b>	<b>Size</b>	<b>Type</b>	<b>Write/read</b>	<b>Definition</b>
IIN	1	Integer	R	Input file unit (Starter input file)
IOUT	1	Integer	R	Output file unit (Starter output file)

9.1.2 Available Engine User's Arguments

<b>Engine User's Arguments – Material Law for Shells</b>				
<b>Variable</b>	<b>Size</b>	<b>Type</b>	<b>Write/read</b>	<b>Definition</b>
NEL	1	Integer	R	Number of elements
UVAR	NUVAR* NEL	Float	R/W	User's variable
UPARAM	NUPARAM	Float	W	User's parameter
NUPARAM	1	Integer	W	Size of UPARAM
NUVAR	1	Integer	W	Number of user's variables
NFUNCT	1	Integer	W	Size of IFUNC
IFUNC	NFUNCT	Integer	W	Function number array
NPF	*	Integer	R	Function array
NPT	1	Integer	R	Number of layers or integration points
IPT	1	Integer	R	Layer or integration point number
IFLAG	*	Integer	R	Geometrical flags
TF	*	Float	R	Function array
NGL	NEL	Integer	R	Element number
TIME	1	Float	R	Current time
TIMESTEP	1	Float	R	Current time step
RHO0	NEL	Float	R	Initial density
AREA	NEL	Float	R	Area
EINT	NEL	Float	R	Total internal energy
THKLY	NEL	Float	R	Layer thickness
EPSPXX	NEL	Float	W	Strain rate XX
DEPSXX	NEL	Float	W	Strain increment XX
EPSXX	NEL	Float	W	Strain XX
SIGOXX	NEL	Float	W	Old elasto-plastic stress XX
SIGNXX	NEL	Float	W	New elasto-plastic stress XX
SIGVXX	NEL	Float	W	Viscous stress XX
SOUNDSP	NEL	Float	W	Sound speed (time step)
VISCMAX	NEL	Float	W	Max damping modulus (time step)
THK	NEL	Float	R/W	Thickness
PLA	NEL	Float	R/W	Plastic strain
OFF	NEL	Float	R/W	Delete flag

<b>Engine User's Arguments – Material Law for Bricks</b>				
<b>Variable</b>	<b>Size</b>	<b>Type</b>	<b>Write/read</b>	<b>Definition</b>
NEL	1	Integer	R	Number of elements
UVAR	NUVAR* NEL	Float	R/W	User's variable
UPARAM	NUPARAM	Float	W	User's parameter
NUPARAM	1	Integer	W	Size of UPARAM
NUVAR	1	Integer	W	Number of user's variables
NFUNCT	1	Integer	W	Size of IFUNC
IFUNC	NFUNCT	Integer	W	Function number array
NPF	*	Integer	R	Function array
TF	*	Float	R	Function array
NGL	NEL	Integer	R	Element number
TIME	1	Float	R	Current time
TIMESTEP	1	Float	R	Current time step
RH00	NEL	Float	R	Initial density
RHO	NEL	Float	R	Density
VOLUME	NEL	Float	R	Volume
EINT	NEL	Float	R	Total internal energy
EPSPXX	NEL	Float	W	Strain rate XX
DEPSXX	NEL	Float	W	Strain increment XX
EPSXX	NEL	Float	W	Strain XX
SIGOXX	NEL	Float	W	Old elasto-plastic stress XX
SIGNXX	NEL	Float	W	New elasto-plastic stress XX
SIGVXX	NEL	Float	W	Viscous stress XX
SOUNDSP	NEL	Float	W	Sound speed (time step)
VISCMAX	NEL	Float	W	Max damping modulus (time step)
OFF	NEL	Float	R/W	Delete flag

<b>Engine User's Arguments – Spring Property</b>				
<b>Variable</b>	<b>Size</b>	<b>Type</b>	<b>Write/read</b>	<b>Definition</b>
NEL	1	Integer	R	Number of elements
IPROP	1	Integer	R	Property number
UVAR	NUVAR* NEL	Float	R/W	User's variable
NUVAR	1	Integer	W	Number of user's variables
FX	NEL	Float	R/W	Tension force
FY	NEL	Float	R/W	Y shear force
FZ	NEL	Float	R/W	Z shear force
XMOM	NEL	Float	R/W	Torsion moment
YMOM	NEL	Float	R/W	Y bending moment
ZMOM	NEL	Float	R/W	Z bending moment
EINT	NEL	Float	R/W	Total internal energy
OFF	NEL	Float	R/W	Delete flag
STIFM	NEL	Float	W	Element stiffness (time step)
STIFR	NEL	Float	W	Element rotation stiffness (time step)

<b>Engine User's Arguments – Spring Property</b>				
<b>Variable</b>	<b>Size</b>	<b>Type</b>	<b>Write/read</b>	<b>Definition</b>
VISCM	NEL	Float	W	Element viscosity (time step)
VISCR	NEL	Float	W	Element rotation viscosity (time step)
MASS	NEL	Float	W	Element mass
XINER	NEL	Float	W	Element inertia (spherical)
DT	1	Integer	R	Time step
XL	NEL	Float	R	Element length
XL	NEL	Float	R	Element length
VX	NEL	Float	R	Tension velocity
RY1	NEL	Float	R	Node 1 Y bending rotational velocity
RZ1	NEL	Float	R	Node 1 Z bending rotational velocity
RX	NEL	Float	R	Torsional velocity
RY2	NEL	Float	R	Node 2 Y bending rotational velocity
RZ2	NEL	Float	R	Node 2 Z bending rotational velocity

<b>Engine User's Arguments</b>				
<b>Variable</b>	<b>Size</b>	<b>Type</b>	<b>Write/read</b>	<b>Definition</b>
NEL	1	Integer	R	Number of elements
IOUT	1	Integer	R	Output file unit (Engine output file)
UVAR	NUVAR* NEL	Float	R/W	User's variable
IPROP	1	Integer	R	Property number
IMAT	1	Integer	R	Material number
SOLID_ID	NEL	Integer	R	Solid Element ID
EINT	NEL	Float	R	Total internal energy
VOL	NEL	Float	R	Initial volume
OFF	NEL	Float	R/W	Delete flag
RHO	NEL	Float	R/W	Density
SIG	6* NEL	Float	R/W	Stress tensor
XX1	NEL	Float	R	X coordinate node 1
YY1	NEL	Float	R	Y coordinate node 1
ZZ1	NEL	Float	R	Z coordinate node 1
XX2 . . ZZ8	NEL	Float	R	Same for node 2 to 8
VX1	NEL	Float	R	X velocity node 1
VY1	NEL	Float	R	Y velocity node 1
VZ1	NEL	Float	R	Z velocity node 1
VRX1	NEL	Float	R	X rotational velocity node 1
VRX1	NEL	Float	R	Y rotational velocity node 1
VRZ1	NEL	Float	R	Z rotational velocity node 1
FX1	NEL	Float	W	X force node 1
FY1	NEL	Float	W	Y force node 1
FZ1	NEL	Float	W	Z force node 1
MX1	NEL	Float	W	X moment node 1
MY1	NEL	Float	W	Y moment node 1
MZ1	NEL	Float	W	Z moment node 1

<b>Engine User's Arguments</b>				
<b>Variable</b>	<b>Size</b>	<b>Type</b>	<b>Write/read</b>	<b>Definition</b>
STIFM	NEL	Float	W	Element stiffness (time step)
STIFR	NEL	Float	W	Element rotation stiffness (time step)
VISCM	NEL	Float	W	Element viscosity (time step)
VISCR	NEL	Float	W	Element rotation viscosity (time step)

<b>Engine User's Arguments – Sensor</b>				
<b>Variable</b>	<b>Size</b>	<b>Type</b>	<b>Write/read</b>	<b>Definition</b>
ID	NEL	Integer	R	Sensor ID



## 9.2 – Appendix 2 – Communication between User's Subroutines and RADIOSS Code

The main functions to access user's properties and materials are return functions and storage functions.

Return Function	Variables	Description
INTEGER <i>IP</i> = <i>GET_U_P</i> ( <i>PID</i> )	<i>PID</i> Integer property ID	Returns a property number.
INTEGER <i>PID</i> = <i>GET_U_PID</i> ( <i>IP</i> )	<i>IP</i> Property number	Returns the user property ID corresponding to the user property number <i>IP</i> .
FLOAT <i>PARAMI</i> = <i>GET_U_GEO</i> ( <i>I,IP</i> )	<i>I</i> Parameter index (1 for the first parameter, ...)	Returns the user geometry parameters.
	<i>IP</i> Property number	
INTEGER <i>II</i> = <i>GET_U_PNU</i> ( <i>I,IP,KK</i> ) IFUNCI = <i>GET_U_PNU</i> ( <i>I,IP,KFUNC</i> ) IPROPI = <i>GET_U_PNU</i> ( <i>I,IP,KPROP</i> ) IMATI = <i>GET_U_PNU</i> ( <i>I,IP,KMAT</i> )	<i>I</i> Parameter index	Returns the user-stored function (if <i>KK</i> = <i>KFUNC</i> ), material (if <i>KK</i> = <i>KMAT</i> ), or property (if <i>KK</i> = <i>KPROP</i> ) numbers.  See Starter subroutine for corresponding ID storage.
	<i>IP</i> Property number	
	<i>KK</i> Parameters <i>KFUNC</i> , <i>KMAT</i> , <i>KPROP</i>	
INTEGER <i>IM</i> = <i>GET_U_M</i> ( <i>MID</i> )	<i>MID</i> Material ID	Returns a material number.
INTEGER <i>MID</i> = <i>GET_U_MID</i> ( <i>IM</i> )	<i>IM</i> Material number	Returns the user material ID corresponding to user material number <i>IM</i> .
FLOAT <i>PARAMI</i> = <i>GET_U_MAT</i> ( <i>I,IM</i> )	<i>I</i> Parameter index	Returns the user material parameters. <b>Note:</b> <i>GET_U_MAT</i> (0, <i>IMAT</i> ) returns the density.
	<i>IM</i> Material number	
INTEGER IFUNCI = <i>GET_U_MNU</i> ( <i>I,IM,KFUNC</i> )	<i>I</i> Variable index	Returns the user-stored function numbers (function referred by user's materials).  See the Starter material user's subroutine for corresponding ID storage.
	<i>IM</i> Material number	
	<i>KFUNC</i> Only functions are yet available	
FLOAT <i>Y</i> = <i>GET_U_FUNC</i> ( <i>IFUNC,X,DYDX</i> )	<i>IFUNC</i> Function numbered obtained by <i>IFUNC</i> = <i>GET_U_MNU</i> ( <i>I,IM,KFUNC</i> ) or <i>IFUNC</i> = <i>GET_U_PNU</i> ( <i>I,IP,KFUNC</i> )	Returns <i>Y</i> ( <i>X</i> ).
	<i>X</i> X value	
	<i>DYDX</i> Slope <i>dY/dX</i>	

GET\_TABLE\_VALUE(NSENS, XX0, XDIM, tmp)

**Storage Function**

**Description**

```
INTEGER ierror = SET_U_PNU(func_index, fun_id,
KFUNC)
```

Stores RADIOSS function `fun_id` in the current user property buffer at a position referenced by `func_index`.

```
INTEGER ierror = SET_U_PNU(mat_index, mid, KMAT)
```

Stores RADIOSS material `mid` in the current user property buffer at a position referenced by `mat_index`.

```
INTEGER ierror = SET_U_PNU(prop_index, pid,
KPROP)
```

Stores RADIOSS property `pid` in the current user property buffer at a position referenced by `prop_index`.

```
INTEGER ierror = SET_U_GEO(value_index, value)
```

Stores a value in the current user property buffer at a position referenced by `value_index`.

**Notes:** The geometry data (property) must be stored in RADIOSS storage with function `SET_U_GEO(value_index,value)`.

If some standard RADIOSS functions (time or x,y) are used, function IDs must be stored with function `SET_U_PNU(func_index,func_id,KFUNC)`.

If the property refers to user material, material IDs must be stored with function `SET_U_PNU(mat_index,mat_id,KMAT)`.

If the property refers to user property, sub-property IDs must be stored with function `SET_U_PNU(sub_prop_index,sub_prop_id,KPROP)`.

`SET_U_GEO` and `SET_U_PNU` return 0 if there are no errors.

`SET_U_GEO` and `SET_U_PNU` return the maximum allowed index if the index is larger than this maximum.

For TABLES use the subroutine: `GET_TABLE_VALUE`

INTEGER: `TABLE_id = GET_NUMTABLE(TableID)`


`GET_TABLE_VALUE(TABLE_id, XX, X_DIM,YY)`, where `XX` is the input vector of dimension `X_DIM` and `YY` is the returned value.

Specific functions for user's subroutines type sensor include those below.

Function	Variables	Description
<i>INTEGER NUM = GET_U_NUMSENS(ID)</i>	ID Sensor ID	Allows you to get a sensor number.
	NUM Sensor number	
<i>INTEGER ierror = GET_U_SENS_FPAR(IVAR, VAR)</i>	IVAR Float variable index	Allows you to retrieve a float sensor parameter.
	VAR Integer value	
<i>INTEGER ierror = GET_U_SENS_IPAR(IVAR, VAR)</i>	IVAR Integer variable index	Allows you to retrieve an integer sensor parameter.
	VAR Integer value	
<i>INTEGER ierror = SET_U_SENS_VALUE(NSENS, IVAR, VAR)</i>	NSENS Integer sensor number	Allows you to write a variable to a sensor buffer (float).
	IVAR Integer buffer index	
	VAR Float value	
<i>INTEGER ierror = GET_U_SENS_VALUE(NSENS, IVAR, VAR)</i>	NSENS Integer sensor number	Allows you to read a variable from a sensor buffer (float).
	IVAR Integer buffer index	
	VAR Float value	
<i>INTEGER ierror = SET_U_SENS_ACTI(NSENS)</i>	NSENS Integer sensor number	Allows you to activate a sensor using RADIOSS flag.
<i>FLOAT DTIME = GET_U_SENS_ACTI(NSENS)</i>	DTIME Float time delay since first activation. (actif <= > DTIME > 0)	Allows you to check RADIOSS activation status of a sensor.
	NSENS Integer sensor number	
<i>FLOAT TIME = GET_U_TIME()</i>		Allows you to check the current time.
<i>INTEGER NCYC = GET_U_CYCLE()</i>		Allows you to check the current cycle.
<i>INTEGER IERR = GET_U_ACCEL(NACC, AX, AY, AZ)</i>	AX, AY, AZ Float acceleration components	Allows you to access accelerometer values.
	NACC Integer accelerator number	
	IDACC Integer accelerator ID	
	NACC GET_U_NUMACC( IDACC)	
<i>INTEGER IERR = GET_U_NOD_X(NOD, X, Y, Z)</i>	X, Y, Z Float nodal coordinates	Allows you access to nodal values.
<i>INTEGER IERR = GET_U_NOD_D(NOD, DX, DY, DZ)</i>	DX, DY, DZ Float nodal displacements	
<i>INTEGER IERR = GET_U_NOD_V(NOD, VX, VY, VZ)</i>	VX, VY, VZ Float nodal velocities	
<i>INTEGER IERR = GET_U_NOD_A(NOD, AX, AY, AZ)</i>	AX, AY, AZ Float nodal accelerations	
	NOD Integer node number	

Function	Variables		Description
INTEGER <i>IERR</i> = <i>GET_U_NOD_A</i> ( <i>NOD</i> , <i>AX</i> , <i>AY</i> , <i>AZ</i> )	NID	Integer node ID	
	NOD	<i>GET_U_NUMNOD</i> (ID)	
FLOAT <i>Y</i> = <i>GET_U_FUNC</i> ( <i>IFUNC</i> , <i>X</i> , <i>DERI</i> )	X	Float ordinate	Allows you to access RADIOSS functions.
	Y	Float abscissa	
	DERI	Float Y/X	
	IFUNC	Integer function number	
	IDFUN	Integer function ID, where INTEGER <i>IFUNC</i> = <i>GET_U_NUMFUN</i> (IDFUN)	

Figure 2: Communication between user's modules and RADIOSS database




### 9.3 – Appendix 3 – General User's Subroutine Format with Material Laws 29, 30, and 31

#### 9.3.1 Example Starter Format

```

SUBROUTINE LECM29 ( IIN, IOUT, UPARAM, MAXUPARAM, NUPARAM,
.                 NUVAR, IFUNC, MAXFUNC, NFUNC, PARMAT )
C
C-----
C  Dummy Arguments
C-----
      INTEGER IIN, IOUT, MAXUPARAM, NUPARAM, NUVAR, MAXFUNC, NFUNC,
.         IFUNC (MAXFUNC)
      DOUBLE PRECISION UPARAM (MAXUPARAM), PARMAT (*)
C
C-----
C  Local Variables
C-----
      DOUBLE PRECISION E, NU, G, A11
C
C-----
C  User's Data Reading
C-----
      READ ( IIN, ' (2F20.0) ' ) E, NU
      A11 = E * (1.-NU) / (1.+NU) / (1.-2.*NU)
      A12 = E * NU / (1.+NU) / (1.-2.*NU)
C
C-----
C  Check
C-----
      IF (NU.LT.0.0.OR.NU.GE.0.5) THEN
          WRITE (IOUT, *) ' ** ERROR : WRONG NU VALUE '
      ENDIF
C
C-----
C  User's Argumenents Definition
C-----
      NUVAR = 2
      NFUNC = 0
      NUPARAM = 3
      UPARAM (1) = E
      UPARAM (2) = A11
      UPARAM (3) = A12
C
C-----
C  Output File Print
C-----
      WRITE (IOUT, 1000)
      WRITE (IOUT, 1100) E, NU
1000 FORMAT (
& 5X, ' MATERIAL LAW 29', /,
1100 FORMAT (
& 5X, 'E . . . . .=' , E12.4 /
& 5X, 'NU. . . . .=' , E12.4 // )
C
      RETURN
      END
    
```



### 9.3.2 Example Engine Format

```

SUBROUTINE SIGEPS29C(
1  NEL      ,NUPARAM,NUVAR  ,NFUNC  ,IFUNC  ,
2  NPF      ,NPT      ,IPT    ,IFLAG  ,
2  TF       ,TIME     ,TIMESTEP,UPARAM ,RHO0   ,
3  AREA    ,EINT     ,THKLY   ,
4  EPSPIX  ,EPSPIY   ,EPSPIX  ,EPSPIZ  ,EPSPIX  ,
5  DEPSXX  ,DEPSYY  ,DEPSXY  ,DEPSYZ  ,DEPSZX  ,
6  EPSXX   ,EPSYY   ,EPSXY   ,EPSYZ   ,EPSZX   ,
7  SIGOXX  ,SIGOYY  ,SIGOXY  ,SIGOYZ  ,SIGOZX  ,
8  SIGNXX  ,SIGNYY  ,SIGNXY  ,SIGNYZ  ,SIGNZX  ,
9  SIGVXX  ,SIGVYY  ,SIGVXY  ,SIGVYZ  ,SIGVZX  ,
A  SOUNDSP ,VISCMAX,THK     ,PLA     ,UVAR   ,
B  OFF     ,NGL     ,SHF    )
C
C-----
C  INPUT Arguments
C-----
      INTEGER NEL,NUPARAM,NUVAR
      DOUBLE PRECISION UPARAM(NUPARAM) ,
      .  DEPSXX(NEL),DEPSYY(NEL) ,
      .  SIGOXX(NEL),SIGOYY(NEL)
C
C-----
C  OUTPUT Arguments
C-----
      DOUBLE PRECISION SIGNXX(NEL),SIGNYY(NEL)
C
C-----
C  INPUT OUTPUT Arguments
C-----
      DOUBLE PRECISION UVAR(NEL,NUVAR)
C
C-----
C  Local Variables
C-----
      INTEGER I
      DOUBLE PRECISION A1,A2
C
C-----
C  User's Program
C-----
      DO I=1,NEL
        A1 = UPARAM(2)
        A2 = UPARAM(3)
        SIGNXX(I)=SIGOXX(I)+A1*DEPSXX(I)+A2*DEPSYY(I)
        SIGNYY(I)=SIGOYY(I)+A2*DEPSXX(I)+A1*DEPSYY(I)
        UVAR(I,1) = SIGNXX(I)
        UVAR(I,2) = SIGNYY(I)
      ENDDO
C
      RETURN
      END

```

Standardized headers:  
**User's arguments list**  
(read, written or read/written)

Input arguments:  
Used in current routine (user's program)

Output arguments:  
Computes in current routine

User's variable:  
Used in communications between user's subroutines

Local variables:  
Used in current user's subroutine

User's program (on elements: NEL):  
Reads input arguments and writes output arguments

The user's variables UVAR can be saved in animations file:  
UVAR(I,1) saved as User Var 1 in animations using /ANIM/ELEM/USER. option in Engine input file.

## 9.4 – Appendix 4 – General User's Subroutine Format with Extended User Material Laws

### 9.4.1 Example Starter Format

```

SUBROUTINE LECMUSERnn(IIN IOUT,UPARAM,MAXUPARAM,NUPARAM,
. NUVAR,IFUNC,MAXFUNC,NFUNC,PARMAT)
C
C-----
C Dummy Arguments
C-----
      INTEGER IIN,IOUT,MAXUPARAM,NUPARAM,NUVAR,MAXFUNC,NFUNC,
      . IFUNC(MAXFUNC)
      DOUBLE PRECISION UPARAM(MAXUPARAM),PARMAT(*)
C
C-----
C Local Variables
C-----
      DOUBLE PRECISION E,NU,G,A11
C
C-----
C User's Data Reading
C-----
      READ(IIN,'(2F20.0)')E,NU
      A11 = E * (1.-NU) / (1.+NU) / (1.-2.*NU)
      A12 = E * NU / (1.+NU) / (1.-2.*NU)
C
C-----
C Check
C-----
      IF(NU.LT.0.0.OR.NU.GE.0.5)THEN
        WRITE(IOUT,*)' ** ERROR : WRONG NU VALUE'
      ENDIF
C
C-----
C User's Argumenents Definition
C-----
      NUVAR = 2
      NFUNC = 0
      NUPARAM = 3
      UPARAM(1) = E
      UPARAM(2) = A11
      UPARAM(3) = A12
C
C-----
C Output File Print
C-----
      WRITE(IOUT,1000)
      WRITE(IOUT,1100)E,NU
1000 FORMAT(
& 5X,' MATERIAL LAW 12',/)
1100 FORMAT(
& 5X,'E . . . . .=' ,E12.4/
& 5X,'NU. . . . .=' ,E12.4//)C
      RETURN
      END

```

Standardized headers:  
**User's arguments list**  
(read, written or read/written)

Arguments:  
Used in communications between  
RADIOSS database and user's  
subroutines

Local variables:  
Used in current user's subroutine

User's data reading:  
Reads input user's data specified  
in RADIOSS Starter input file  
(user's options: /MAT/USER1/)

Check:  
Write message

Argument definition:  
Stores user's arguments values as  
user's parameters

There can be returned by a restore  
function in the Engine user's  
subroutine

File print:  
Prints user's values in Starter  
output file



### 9.4.2 Example Engine Format

```

SUBROUTINE LUSERnnC(
1  NEL      ,NUPARAM,NUVAR  ,NFUNC  ,IFUNC  ,
2  NPF      ,NGL
2  TF       ,TIME      ,TIMESTEP,UPARAM  ,RHO0  ,
3  AREA    ,EINT      ,SHF    ,
4  SOUNDSP,VISCMAX    ,PLA    ,UVAR    ,
5  OFF     ,SIGY      ,USERBUF)
C
C-----
C  INPUT Arguments
C-----
      INTEGER NEL,NUPARAM,NUVAR
      DOUBLE PRECISION UPARAM(NUPARAM) ,
      .  DEPSXX(NEL),DEPSYY(NEL) ,
      .  SIGOXX(NEL),SIGOYY(NEL)
C
C-----
C  OUTPUT Arguments
C-----
      DOUBLE PRECISION SIGNXX(NEL) ,SIGNYY(NEL)
C
C-----
C  INPUT OUTPUT Arguments
C-----
      DOUBLE PRECISION UVAR(NEL,NUVAR)
C
C-----
C  Local Variables
C-----
      INTEGER I
      DOUBLE PRECISION A1,A2
C
C-----
C  User's Program
C-----
      DO I=1,NEL
        A1 = UPARAM(2)
        A2 = UPARAM(3)
        SIGNXX(I)=SIGOXX(I)+A1*DEPSXX(I)+A2*DEPSYY(I)
        SIGNYY(I)=SIGOYY(I)+A2*DEPSXX(I)+A1*DEPSYY(I)
        UVAR(I,1) = SIGNXX(I)
        UVAR(I,2) = SIGNYY(I)
      ENDDO
C
RETURN
END

```

Standardized headers:  
**User's arguments list**  
(read, written or read/written)

Input arguments:  
Used in current routine (user's program)

Output arguments:  
Computes in current routine

User's variable:  
Used in communications between user's subroutines.

Local variables:  
Used in current user's subroutine

User's program (on elements: NEL):  
Reads input arguments and writes output arguments

The user's variables UVAR can be saved in animations file:  
UVAR(I,1) saved as User Var 1 in animations using /ANIM/ELEM/USER1 option in 0001.rad.